
# FORENO.



Congratulations on your purchase of this high quality product from Foreno Tapware. Please read the following before installation and retain (along with your receipt) for future reference.

#### **TECHNICAL SPECIFICATIONS**


## Suitable for Mains Pressure Only

Minimum Pressure = 150kPa Maximum operating Pressure = 500kPa\* (As per NZ Building Code AS/NZ 3500.1) Maximum operating Temperature = 65 deg. Celsius

For domestic use only.

#### CONFIGURATION

Mains Pressure systemsInstall as supplied.Unequal Low systemsNot suitable.Equal Low systemsNot suitable.



#### INSTALLATION

## \*FOR PRESSURES EXCEEDING 500kPa INSTALL A PRESSURE REDUCING VALVE. BEFORE CONNECTING ANY TAPWARE, THOROUGHLY FLUSH ALL PIPES TO ELIMINATE ANY REMAINING DIRT AND RESIDUE, AND INSTALL INLINE FILTERS. FAILURE TO DO SO MAY VOID THE WARRANTY.

- This spout has a **FEMALE PLUMBING CONNECTION**. An appropriate MALE connection should be installed within the wall with adequate length for screwing the spout on after finished wall lining is fitted.
- Screw spout onto plumbing connection, using adequate PTFE tape or hemp to ensure a water tight seal.
- Turn on the water supply.
- Check for leaks and for correct operation.

#### WARRANTY

Please refer to our website for warranty information: www.foreno.co.nz/warranty

In the unlikely event that this product fails during its warranty period, phone our Customer Service team immediately on 0508 FORENO (0508 367 366) – as unauthorised removal of the product may void the warranty.

#### CARE AND MAINTENANCE

### SHOULD NOT BE CLEANED WITH ACIDIC, CAUSTIC/ALKALINE, ABRASIVE OR CITRIC CLEANERS.

A soft, damp cloth is recommended for cleaning (Not a Micro fibre cloth). Mild soap solutions can also be used on occasion.

See FORENO. website for full care instructions: www.foreno.co.nz/tapware-care-instructions/